

How to Store

1. Open the carrying case and place the CUBE Street EX inside.



2. Tighten the strap on the top of the carrying case to secure the case and the unit in place.



When transporting the unit, close the fasteners on both sides. When moving the unit, hold it by the handle on the CUBE Street EX itself. (Never grasp the unit by the strap on the case.)

3. When using during a performance, fold back the cover and secure it in place with the hook-and-loop fastener.



When positioning the unit, arrange it so that the feet will not get entangled in the shoulder belt.

Main Specifications

Roland CB-CS2: Carrying Case for CUBE Street EX

Compatible Models	CUBE Street EX
Main Material	Polyvinyl chloride, Polyester
Dimensions (excluding protruding parts)	510 (W) x 350 (D) x 320 (H) mm 20-1/8 (W) x 13-13/16 (D) x 12-5/8 (H) inches
Weight	1.0 kg / 2 lbs 4 oz

* In the interest of product improvement, the specifications and/or appearance of this product are subject to change without prior notice.

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
⊘	The ⊘ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
⚡	The ⚡ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

Do not disassemble or modify by yourself

Do not carry out anything unless you are instructed to do so in the owner's manual. Otherwise, you risk causing malfunction.



Do not use or store in the following types of locations

- Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
- Damp (e.g., baths, washrooms, on wet floors); or are
- Exposed to steam or smoke; or are
- Subject to salt exposure; or are
- Exposed to rain; or are
- Dusty or sandy; or are
- Subject to high levels of vibration and shakiness.



⚠ WARNING

Be cautious to protect children from injury

Always make sure that an adult is on hand to provide supervision and guidance when using this product in places where children are present, or when a child will be using this product.



Do not drop this case or subject it to strong impact while your instrument is stored in it

Otherwise, you risk causing damage or malfunction.



IMPORTANT NOTES

Placement

- Do not expose this product to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor this product.

Maintenance

- For everyday cleaning wipe this product with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe this product thoroughly with a soft, dry cloth.

- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

- Do not launder or wash the entire bag.

Additional Precautions

- To avoid risk of injury or product damage, never use this carrying case when the CUBE Street EX is mounted on a speaker stand.

Trademarks

- Roland, CUBE, and CUBE Street are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

For C.A. US (Proposition 65)

WARNING

This product contains chemicals known to cause cancer, birth defects and other reproductive harm, including lead.

収納方法

1. キャリング・ケースを開き、CUBE Street EX を収納します。



2. キャリング・ケース上面の固定バンドを締め、ケースと本体を固定します。



運搬時は、両側のファスナーを閉めます。移動の際は、CUBE Street EX 本体の取っ手を持つようにしてください（ケース固定バンドを持たないでください）。

3. 演奏時には、ふたを巻き、面ファスナーで固定します。



設置の際は、ショルダー・ベルトに足を引っ掛けられないように処理してください。

主な仕様

ローランド CB-CS2 : CUBE Street EX キャリング・ケース

対応機種	CUBE Street EX
主な材料	ポリ塩化ビニール、ポリエステル
外形寸法 (突起物を除く)	510 (幅) × 350 (奥行) × 320 (高さ) mm
質量	1.0kg

※ 製品の仕様や外観は、改良のため予告なく変更することがあります。

安全上のご注意

火災・感電・傷害を防止するには

△警告と△注意の意味について

警告	取り扱いを誤った場合に、使用者が死にまたは重傷を負う可能性が想定される内容を表示しています。
注意	取り扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表示しています。 ※物的損害とは、家屋・家財および家畜・ペットにかかわる拡大損害を表示しています。

図記号の例

△	注意 (危険、警告を含む) を表しています。具体的な注意内容は、△の中に描かれています。左図の場合は、「一般的な注意、警告、危険」を表しています。
⊘	禁止 (してはいけないこと) を表しています。具体的な禁止内容は、⊘の中に描かれています。左図の場合は、「分解禁止」を表しています。
●	強制 (必ずすること) を表しています。具体的な強制内容は、●の中に描かれています。左図の場合は、「電源プラグをコンセントから抜くこと」を表しています。

以下の指示を必ず守ってください

警告

分解や改造をしない

取扱説明書に書かれていないことはしないでください。故障の原因になります。



次のような場所で使用や保管はしない

- 温度が極端に高い場所 (直射日光の当たる場所、暖房機器の近く、発熱する機器の上など)
- 水気の近く (風呂場、洗面台、濡れた床など) や湿度の高い場所
- 湯気や油煙が当たる場所
- 塩害の恐れがある場所
- 雨に濡れる場所
- ほこりや砂ぼこりの多い場所
- 振動や揺れの多い場所



警告

お子様がけがをしないように注意する

お子様のいる場所で使用する場合は、必ず大人のかたが、監視/指導してあげてください。



製品を収納した状態で、落としたり、強い衝撃を与えたりしない

破損や故障の原因になります。



使用上のご注意

設置について

- 直射日光の当たる場所や発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。

お手入れについて

- 通常のお手入れは、柔らかい布で乾拭きするか、固く絞った布で汚れを拭き取ってください。汚れが激しいときは、中性洗剤を含んだ布で汚れを拭き取ってから、柔らかい布で乾拭きしてください。
- 変色や変形の原因となる、ベンジン、シンナー、アルコール類は使用しないでください。
- 丸洗いしないでください。

その他の注意について

- この製品が入っていた梱装箱や緩衝材を廃棄するときは、各地域のゴミの分別基準に従ってください。
- CUBE Street EX をスピーカー・スタンドに取り付けて使うときは、本製品を使用しないでください。

商標について

- Roland、CUBE、CUBE Street は、日本国およびその他の国におけるローランド株式会社の登録商標または商標です。
- 文中記載の会社名および製品名は、各社の登録商標または商標です。

© 2014 ローランド株式会社 本書の一部、もしくは全部を無断で複製・転載することを禁じます。

