

Tapo Robot Vacuum Disposable Dust Bag

Replacement Instructions

1. Open the top cover and pull up the handle of the dust bag to remove.




2. Throw away the used dust bag when it is full.



3. Install a new dust bag and put the cover back on.



A Put the cover back on each time you open it, especially before auto-emptying.



@2024 TP-Link 7106511891 REV1.0.0

