

Operating Instructions

Soloroll® II



Congratulations

With a purchase of a Griesser product, you have chosen quality.

Please read these instructions before using the product for the first time.

General Information

Interior blinds provide solar shading. They should not be considered security equipment.

The operating instructions must be handed out to the user and to the person responsible for the maintenance.



General Hazard and Safety Information

- Property damage and bodily injury may result from improper handling or disregarding safety information.
- In the event of damages resulting from non-observance of these instructions or of the accompanying documentation, all warranty claims become null and void.
- Griesser AG accepts no liability for consequential losses or damages.

Notice of strangulation hazard

- To avoid strangulation, products with bead chains as operating elements must be kept out of the reach of small children. Beds, furniture, etc. must be placed at a safe distance from the operating elements. The operating elements must not be tied together so that no loops can form.



Safety Information for Operation and Use

Risk of injury or damage to the product from improper operation

- Attach operating controls within view of the curtain, in accordance with national regulations.
- Keep operating controls out of the reach of children.
- May only be operated by instructed persons.
- Do not touch moving parts when deploying or retracting blinds.
- Do not allow jewelry, clothing, hair or body parts to become entangled in the product.
- Risk of crushing obstacles in the deployment area.
- Stand clear until the end position has been reached.
- Placing additional weight on facade awnings by attaching objects or tension cables may lead to damage or cause facade awnings to fall from their anchoring and is therefore not permitted.
- Do not touch any interior parts that are exposed due to damage (e.g. cables/cords, control elements).

Risk of injury due to inadequate maintenance

- Check products regularly for signs of wear.
- Do not use products that require repairs.
- Malfunctions may only be rectified by trained and qualified personnel.

Use only original Griesser replacement parts

- No assurance is provided that the product will function with accessories, parts or operating equipment made by other manufacturers. Modifications to the product that are not expressly approved by Griesser render warranty or product liability claims null and void.

Risk of injury or damage to the product from unintentional operation

- Disconnect products from the power supply power when maintenance work is taking place.
- Observe safety distances.

Risk of damage to the product from improper operation

- When operating manually, do not use force to open or close the awning.
- Do not operate products beyond their mechanical limits.
- Never leave the blinds in the lowered position if the window is open wide and ensure that negative pressure does not develop.

Risk of injury and damage to the product from interruptions to the power supply (e.g. power outages)

Ensure that situations dangerous to people and the product do not arise



Electrical Installations

Electrical connections may only be carried out by certified electricians

- Additional national regulations regarding the maintenance and repair of electrical systems shall be observed. These may result in an increase in the maintenance intervals.

Operation

Motorized operation

Awnings are operated using central or local wall-mounted or hand-held controls with an Up/Down/Stop button. The operating functions of the controls are described in the operating instructions for the controls.

Manual operation

Awnings are operated using a chain, articulated crank or hook-in crank.

Use

- Internal roller blinds provide solar shading and may not be used as security equipment.
- When operating a facade awning, ensure that no obstacles (flower pots, toys, chairs, etc.) are located in the awning's path.
- Never lower the blind with the window open (European standards and guidelines).
- When operating the blinds manually, stand directly in front of the chain attachment point to operate the blind and make sure, that it runs smoothly.
- When operating the blind manually, do not use force if the interior blind jams. Change the direction of rotation in order to check if the shutter has reached the end of the track.

Maintenance / Inspection

Soloroll requires no special maintenance beyond retensioning the cords. The mechanism is lubricated for life (approx. 15 years). All aluminum profiles are enameled or anodized; all steel elements are treated with rust protection.

Intervalle	Location (depending on guides)	Task
Anually	Cord tension (Perlon cord)	<ul style="list-style-type: none">• Check the cord tension• Retension, if necessary

Any repairs are to be made by a specialized company.

Cleaning

Cleaning agents with alkaline, acidic or abrasive active ingredients and pressurized steam cleaning may not be used!

- Box, guide rails, end rails:
Clean with a damp cloth or sponge, using only soapy water, or brush with a soft brush. Scrub thoroughly with clear water and dry.
- Fabrics | Clean once a year as follows:
 - PVC textiles (Polaris and Vega): Wipe with a damp cloth. Use only soapy water.
 - Non-PVC textiles (Sirius): Rub carefully with a greaseless, white rubber eraser.

Inspired by the **Sun.**

griesser.com

