

| Marca | Modello |
|-------|---------------------------|
| APPLE | iPhone 11 (A2111) |
| | iPhone 11 (A2221) |
| | iPhone 11 (A2222) |
| | iPhone 11 (A2223) |
| | iPhone 11 Pro (A2160) |
| | iPhone 11 Pro (A2215) |
| | iPhone 11 Pro (A2216) |
| | iPhone 11 Pro (A2217) |
| | iPhone 11 Pro Max (A2161) |
| | iPhone 11 Pro Max (A2218) |
| | iPhone 11 Pro Max (A2219) |
| | iPhone 11 Pro Max (A2220) |
| | iPhone 12 (A2172) |
| | iPhone 12 (A2402) |
| | iPhone 12 (A2403) |
| | iPhone 12 (A2404) |
| | iPhone 12 mini (A2176) |
| | iPhone 12 mini (A2398) |
| | iPhone 12 mini (A2399) |
| | iPhone 12 mini (A2400) |
| | iPhone 12 Pro (A2341) |
| | iPhone 12 Pro (A2406) |
| | iPhone 12 Pro (A2407) |
| | iPhone 12 Pro (A2408) |
| | iPhone 12 Pro Max (A2342) |
| | iPhone 12 Pro Max (A2410) |
| | iPhone 12 Pro Max (A2411) |
| | iPhone 12 Pro Max (A2412) |
| | iPhone 13 (A2482) |

| | |
|--|---------------------------|
| | iPhone 13 (A2631) |
| | iPhone 13 (A2633) |
| | iPhone 13 (A2634) |
| | iPhone 13 (A2635) |
| | iPhone 13 mini (A2481) |
| | iPhone 13 mini (A2626) |
| | iPhone 13 mini (A2628) |
| | iPhone 13 mini (A2629) |
| | iPhone 13 mini (A2630) |
| | iPhone 13 Pro (A2483) |
| | iPhone 13 Pro (A2636) |
| | iPhone 13 Pro (A2638) |
| | iPhone 13 Pro (A2639) |
| | iPhone 13 Pro (A2640) |
| | iPhone 13 Pro Max (A2484) |
| | iPhone 13 Pro Max (A2641) |
| | iPhone 13 Pro Max (A2643) |
| | iPhone 13 Pro Max (A2644) |
| | iPhone 13 Pro Max (A2645) |
| | iPhone 14 (A2649) |
| | iPhone 14 (A2881) |
| | iPhone 14 (A2882) |
| | iPhone 14 (A2883) |
| | iPhone 14 (A2884) |
| | iPhone 14 Plus (A2632) |
| | iPhone 14 Plus (A2885) |
| | iPhone 14 Plus (A2886) |
| | iPhone 14 Plus (A2887) |
| | iPhone 14 Plus (A2888) |
| | iPhone 14 Pro (A2650) |
| | iPhone 14 Pro (A2889) |

| | |
|--|---------------------------|
| | iPhone 14 Pro (A2890) |
| | iPhone 14 Pro (A2891) |
| | iPhone 14 Pro (A2892) |
| | iPhone 14 Pro Max (A2651) |
| | iPhone 14 Pro Max (A2893) |
| | iPhone 14 Pro Max (A2894) |
| | iPhone 14 Pro Max (A2895) |
| | iPhone 14 Pro Max (A2896) |
| | iPhone 15 (A2846) |
| | iPhone 15 (A3089) |
| | iPhone 15 (A3090) |
| | iPhone 15 (A3092) |
| | iPhone 15 Plus (A2847) |
| | iPhone 15 Plus (A3093) |
| | iPhone 15 Plus (A3094) |
| | iPhone 15 Plus (A3096) |
| | iPhone 15 Pro (A2848) |
| | iPhone 15 Pro (A3101) |
| | iPhone 15 Pro (A3102) |
| | iPhone 15 Pro (A3104) |
| | iPhone 15 Pro Max (A2849) |
| | iPhone 15 Pro Max (A3105) |
| | iPhone 15 Pro Max (A3106) |
| | iPhone 15 Pro Max (A3108) |
| | iPhone 16 (A3081) |
| | iPhone 16 (A3286) |
| | iPhone 16 (A3287) |
| | iPhone 16 (A3288) |
| | iPhone 16 Plus (A3082) |
| | iPhone 16 Plus (A3289) |
| | iPhone 16 Plus (A3290) |

| | |
|--|-------------------------------|
| | iPhone 16 Plus (A3291) |
| | iPhone 16 Pro (A3083) |
| | iPhone 16 Pro (A3292) |
| | iPhone 16 Pro (A3293) |
| | iPhone 16 Pro (A3294) |
| | iPhone 16 Pro Max (A3084) |
| | iPhone 16 Pro Max (A3295) |
| | iPhone 16 Pro Max (A3296) |
| | iPhone 16 Pro Max (A3297) |
| | iPhone SE 2020 (A2275) |
| | iPhone SE 2020 (A2296) |
| | iPhone SE 2020 (A2297) |
| | iPhone SE 2020 (A2298) |
| | iPhone SE 3rd edition (A2595) |
| | iPhone SE 3rd edition (A2782) |
| | iPhone SE 3rd edition (A2783) |
| | iPhone SE 3rd edition (A2784) |
| | iPhone SE 3rd edition (A2785) |
| | iPhone XR (A1984) |
| | iPhone XR (A2105) |
| | iPhone XR (A2106) |
| | iPhone XR (A2107) |
| | iPhone XR (A2108) |
| | iPhone XS (A1920) |
| | iPhone XS (A2097) |
| | iPhone XS (A2098) |
| | iPhone XS (A2099) |
| | iPhone XS (A2100) |
| | iPhone XS MAX (A1921) |
| | iPhone XS MAX (A2101) |
| | iPhone XS MAX (A2102) |

| | |
|--|-----------------------|
| | iPhone XS MAX (A2103) |
| | iPhone XS MAX (A2104) |