






安全上のご注意

火災・感電・傷害を防止するには

△警告と△注意の意味について

 警告	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
 注意	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。 ※物的損害とは、家屋・家財および家畜・ペットにかかわる拡大損害を表わしています。

図記号の例

	△は、注意（危険、警告を含む）を表わしています。具体的な注意内容は、△の中に描かれています。左図の場合は、「一般的な注意、警告、危険」を表わしています。
	⊘は、禁止（してはいけないこと）を表わしています。具体的な禁止内容は、⊘の中に描かれています。左図の場合は、「分解禁止」を表わしています。
	●は、強制（必ずすること）を表わしています。具体的な強制内容は、●の中に描かれています。左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

----- 以下の指示を必ず守ってください -----

警告

- 製品を収納した状態で本製品を落としたり、強い衝撃を与えないでください。

使用上のご注意

- 本製品は GT-8/6B、BR-1200CD、RC-50用のケースです。
- 直射日光の当たる場所や、発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。
- 通常のお手入れは、柔らかい布で乾拭きするか、堅く絞った布で汚れを拭き取ってください。汚れが激しいときは、中性洗剤を含んだ布で汚れを拭き取ってから、柔らかい布で乾拭きしてください。
- 変色や変形の原因となるベンジン、シンナーおよびアルコール類は、使用しないでください。
- また、丸洗いはしないでください。

主な仕様



- ・ 外形寸法：
600 (W) x 350 (D) x 100 (H) mm
- ・ 最大収納：
540 (W) x 330 (D) x 80 (H) mm
- ・ 重量：850 g
- ・ 材料：
ナイロン／発泡ウレタン（芯材）

※ 製品の仕様および外観は、改良のため予告なく変更することがあります。




USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About △ WARNING and △ CAUTION Notices

 WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
 CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The △ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⊘ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ● symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

----- ALWAYS OBSERVE THE FOLLOWING -----

WARNING

- Never drop this product or subject it to strong impact while it contains any device.



Important Notes

- This product is a case for the GT-8/6B, BR-1200CD, or RC-50.
- Do not expose the unit to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the unit.
- For everyday cleaning wipe the unit with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.
- Do not launder or wash the entire bag.

Main Specifications

- Dimensions:
600 (W) x 350 (D) x 100 (H) mm
23-5/8 (W) x 13-13/16 (D) x 3-15/16 (H) inches
- Max. Interior Dimensions:
540 (W) x 330 (D) x 80 (H) mm
21-5/16 (W) x 13 (D) x 3-3/16 (H) inches
- Weight:
850 g / 1 lb 14 oz
- Materials:
Front cloth: Nylon,
Inside core: Polyethylene sponge
- * In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.