


# TDM-20/TDM-10 取扱説明書

このたびは、ローランド V-Drums セッティング・マット TDM-20/TDM-10 をご購入いただき、まことにありがとうございます。

この製品を正しくお使いいただくために、ご使用前に「安全上のご注意」と「使用上のご注意」をよくお読みください。また、この製品の優れた機能を十分ご理解いただくためにも、取扱説明書をよくお読みください。取扱説明書は必要とときにすぐに見ることができるよう、手元に置いてください。

## 設置のしかた

- 図のように、Roland ロゴがドラム・セットの右後方になるようにセッティングしてください。
  - キック・ペダルの逃げが気になる場合は、市販のマジックテープの硬い面をキック・ペダルの裏面に貼り付けてご使用ください。キック・ペダルの逃げが改善されます。
- ※ キック・トリガー・パッドのスパイクは、ラバー・フットから5mm以上出さないでください。5mm以上出して使用した場合、本製品を突き抜けて床に傷が付く可能性があります。



## 主な仕様

### 外形寸法

TDM-20: 1600 (幅) × 1500 (奥行) × 8 (厚さ) mm  
TDM-10: 1200 (幅) × 1300 (奥行) × 8 (厚さ) mm

### 質量

TDM-20: 3.0kg  
TDM-10: 2.1kg

### 原材料

パイル: BCF ナイロン  
バックিং: ポリウレタンフォーム+不織布  
タグ: ポリウレタン

※ 本製品には防災・防汚加工、および制電加工を施してあります。

※ 製品の仕様および外観は、改良のため予告なく変更することがあります。

## 安全上のご注意

### 火災・感電・傷害を防止するには

#### ⚠ 警告と ⚠ 注意の意味について

	<b>警告</b>	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
	<b>注意</b>	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。  ※物的損害とは、家屋・家財および家畜・ペットにかかわる拡大損害を表わしています。

#### 図記号の例

	△は、注意（危険、警告を含む）を表わしています。具体的な注意内容は、△の中に描かれています。左図の場合は、「一般的な注意、警告、危険」を表わしています。
	⊘は、禁止（してはいけないこと）を表わしています。具体的な禁止内容は、⊘の中に描かれています。左図の場合は、「分解禁止」を表わしています。
	●は、強制（必ずすること）を表わしています。具体的な強制内容は、●の中に描かれています。左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

以下の指示を必ず守ってください

### ⚠ 警告

- この製品を使用する前に、以下の指示と取扱説明書をよく読んでください。

- 次のような場所での使用や保存はしないでください。

- 温度が極端に高い場所（直射日光の当たる場所、暖房機器の近く、発熱する機器の上など）
- 水気の近く（風呂場、洗面台、濡れた床など）や湿度の高い場所
- 雨に濡れる場所
- ホコリの多い場所
- 振動の多い場所

- この製品は、ローランド V-Drums 専用のセッティング・マットです。他の用途に使用しないでください。

- この製品を、ぐらつく台の上や傾いた場所に設置しないでください。必ず安定した水平な場所に設置してください。

- お子様のいるご家庭で使用する場合、お子様の取り扱いやいたずらに注意してください。必ず大人のかたが、監視/指導してあげてください。

- 本製品には防災加工を施してありますが、故意に燃やさないでください。火災の原因になる場合があります。

## 使用上のご注意

このページに記載されている「安全上のご注意」以外に、次のことに注意してください。

### 設置について

- 本製品は屋内でのみご使用ください。
- 直射日光の当たる場所や、発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。
- 設置条件（設置面の材質、温度など）によっては本製品裏面のスポンジが、設置した面に貼り付いたり、設置した面の表面を変色または変質させたりすることがあります。

### お手入れについて

- 通常のお手入れは、掃除機で表面のほこりを吸い取ってください。汚れが激しいときは、市販のカーペット・クリーナーで汚れを拭き取ってください。丸洗いはしないでください。
- 変色や変形の原因となるベンジン、シンナーおよびアルコール類は、使用しないでください。

### その他の注意について

- 本製品は、日本建築学会「建築物の遮音性能基準と設計指針」において、遮音等級 L 値 45 相当の遮音効果が得られますが、完全に遮音/防振するためのものではありません。
- 本製品の上に何も載っていない状態では、本製品が床の上で滑って動くことがあります。本製品の上に機材などを運び込む際には十分注意してセッティングしてください。




# TDM-20/TDM-10 Owner's Manual

Thank you, and congratulations on your choice of the Roland V-Drums Setting Mat TDM-20/TDM-10.

**Before using this mat, carefully read the sections entitled: "USING THE MAT SAFELY" and "IMPORTANT NOTES" (this page). These sections provide important information concerning the proper operation of the mat. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new mat, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.**

## Setting Up

- Place the mat as shown in the figure, with the Roland logo behind and to the right of the drum set.
- If kick pedal slippage is a concern, attach the hook side of Velcro or other hook-and-loop fastener tape (commercially available) to the underside of the kick pedal. This should help secure the kick pedal.
- \* Ensure that the spike of the kick trigger pad does not extend more than 5 mm from the rubber foot. Use with the spikes extending more than 5 mm allows the spikes to penetrate the mat and damage flooring.



## Specifications

### Dimensions

TDM-20: 1600 (W) x 1500 (D) x 8 (H) mm  
63 (W) x 59-1/16 (D) x 3/8 (H) inches  
TDM-10: 1200 (W) x 1300 (D) x 8 (H) mm  
47-1/4 (W) x 51-3/16 (D) x 3/8 (H) inches

### Weight

TDM-20: 3.0 kg / 6 lbs 10 oz  
TDM-10: 2.1 kg / 4 lbs 11 oz

### Materials

Pile: Nylon Filament  
Backing: Soft Urethane Resin + Felt  
Tag: Polyurethane

\* This product has been treated to resist fire, soiling, and static electricity.

\* In the interest of product improvement, the specifications and/or appearance of this mat are subject to change without prior notice.

Copyright © 2005 ROLAND CORPORATION  
All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

## USING THE MAT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

	Used for instructions intended to alert the user to the risk of death or severe injury should the mat be used improperly.
	Used for instructions intended to alert the user to the risk of injury or material damage should the mat be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

### ⚠ WARNING

- Before using this mat, make sure to read the instructions below, and the Owner's Manual.

- Never use or store the mat in places that are:
  - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
  - Damp (e.g., baths, washrooms, on wet floors); or are
  - Humid; or are
  - Exposed to rain; or are
  - Dusty; or are
  - Subject to high levels of vibration.

- This mat is designed to be used exclusively with Roland V-Drums. Do not use this mat for other purposes or applications.

- Make sure you always have the mat placed so it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces.

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the mat.

- Although this mat has been treated to resist fire, do not burn the mat intentionally. Doing so may cause fire to break out.

### IMPORTANT NOTES

In addition to the items listed under "USING THE MAT SAFELY" on this page, please read and observe the following:

#### Placement

- Use this mat indoors only.
- Do not expose the mat to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the mat.
- Depending on the material and temperature of the surface on which you place the mat, the sponge portion of the mat's underside may adhere to flooring surfaces or cause discoloration or degradation of flooring surface materials.

#### Maintenance

- For routine cleaning, use a vacuum cleaner to remove any dust that may have accumulated on the surface. In case of more serious soiling, use a commercial carpet cleaner to spot-clean, and wipe to remove stains. Do not launder or wash the entire mat.
- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

#### Additional Precautions

- This product is not designed to provide total insulation from sound or vibration.
- This mat may move and slip around over the floor when nothing has yet been placed on top of it. For this reason, you need to be especially careful during setup, when you carry in the equipment you intend to place on the mat.



40672745 2PD