

# MICRO CUBE 専用プロテクティブ・カバー CB-MCC1 取扱説明書

MICRO CUBE 専用プロテクティブ・カバー、CB-MCC1 をお買い上げいただき、まことにありがとうございます。

この製品を正しくお使いいただくために、ご使用前に「使用上のご注意」をよくお読みください。

## 使用上のご注意

- 本製品は、MICRO CUBE 専用のプロテクティブ・カバーです。
- 製品を収納した状態で本製品を落としたり、強い衝撃を与えないでください。
- 収納時および運搬時に、MICRO CUBE 本体の電源スイッチがオンにならないようにご注意ください。
- 直射日光の当たる場所や、発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。
- 変色や変形の原因となるベンジン、シンナーおよびアルコール類は、使用しないでください。
- 丸洗いはしないでください。
- 通常のお手入れは、柔らかい布で乾拭きするか、強く絞った布で汚れを拭き取ってください。汚れが激しいときは、中性洗剤を含んだ布で汚れを拭き取ってから、柔らかい布で乾拭きしてください。

## 主な仕様

- 質量：230g
  - 主な素材：PVC（非フタル酸系可塑剤使用）
- ※ 製品の仕様および外観は、改良のため予告なく変更することがあります。

## CB-MCC1 装着方法


1. MICRO CUBE 本体のストラップを取り外します。



2. カバーを上から被せます。



3. カバー側面の穴から、MICRO CUBE 本体のストラップ・ピンが出るように被せます。



4. ストラップを取り付けます。  
この状態でカバーを装着したまま、演奏ができます。  
電源スイッチのオン/オフ、ACアダプターの接続は、カバー背面の開口部を上げておこなってください。



**【注意】** MICRO CUBE を持ち運ぶときは、カバーのベルトを持たないでください。

5. ファスナーをしめます。  
MICRO CUBE の運搬のときや保管のときは、この状態にします。



# CB-MCC1 Owner's Manual

Thank you, and congratulations on your choice of the CB-MCC1 protective cover for MICRO CUBE.

**Before using this product, carefully read the section entitled: "Important Notes." This section provides important information concerning the proper operation of the product.**

## Important Notes

- This product is a protective cover for the MICRO CUBE.
- Protect the product from strong impact (Do not drop it!).
- Please note that the power switch of the MICRO CUBE doesn't turn on when you store and/or transport it.
- Do not expose the product to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the product.
- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.
- Do not launder or wash the entire cover.
- For everyday cleaning wipe the product with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the product thoroughly with a soft, dry cloth.

## Specifications

- Weight : 230 g
- Material : PVC (non-phthalate plasticizer used)
- \* In the interest of product improvement, the specifications and/or appearance of this product are subject to change without prior notice.

Copyright © 2009 ROLAND CORPORATION  
All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

## Attaching the CB-MCC1


1. Detach the strap from the MICRO CUBE.



2. Place the cover onto the MICRO CUBE from above.



3. Place the cover so that the MICRO CUBE's strap pins extend through the holes in the sides of the cover.



4. Attach the strap.

In this condition, you can perform while leaving the cover in place. To operate the power switch or connect the AC adaptor, spread the opening located on the rear of the cover.



### NOTE

When transporting the MICRO CUBE, do not grasp the belt of the cover.

5. Close the fastener.

Transport or store the MICRO CUBE in this state.



For C.A. US (Proposition 65)

### WARNING

This product contains chemicals known to cause cancer, birth defects and other reproductive harm, including lead.